


dji OSMO POCKET 4P

User Manual

v1.0 2026.06





This document is copyrighted by DJI with all rights reserved. Unless otherwise authorized by DJI, you are not eligible to use or allow others to use the document or any part of the document by reproducing, transferring or selling the document. Only refer to this document and the content thereof as instructions to operate DJI products. The document should not be used for other purposes.

In the event of divergence among different versions, the English version shall prevail.

Searching for Keywords

Search for keywords such as “battery” and “install” to find a topic. If you are using Adobe Acrobat Reader to read this document, press Ctrl+F on Windows or Command+F on Mac to begin a search.

Navigating to a Topic

View a complete list of topics in the table of contents. Click on a topic to navigate to that section.

Printing this Document

This document supports high resolution printing.

Using this Manual

Legend

⚠ Important

💡 Hints and Tips

📖 Reference

Read Before Use

DJI™ provides you with tutorial videos and the following documents:

1. *Safety Guidelines*
2. *Quick Start Guide*
3. *User Manual*

It is recommended to watch all the tutorial videos and read the *Safety Guidelines* before using for the first time. Make sure to review the *Quick Start Guide* before using for the first time and refer to this *User Manual* for more information.

Video Tutorials

Go to the address below or scan the QR code to watch the tutorial videos, which demonstrate how to use the product safely:



<https://www.dji.com/osmo-pocket-4p/video>

Contents

Using this Manual	3
Legend	3
Read Before Use	3
Video Tutorials	3
1 Product Profile	6
1.1 Overview	7
1.2 Handle With 1/4" Thread	8
1.3 Battery Handle	10
1.4 Fill Light	12
1.5 Wide-Angle Lens	13
1.6 Osmo Mini Tripod	15
2 Getting Started	16
2.1 Powering On	16
2.2 Activation	16
2.3 Firmware Update	17
2.4 Charging	17
3 Basic Operations	18
3.1 Button Features	18
3.2 Operating the Touchscreen	20
Camera View	20
Swipe Up - Parameter Settings	21
Swipe Left - Image and Audio Settings	21
Swipe Right - Playback	22
Swipe Down - Control Center	22
3.3 Remote Controller Operations	25
Button Features	25
Operating the Touchscreen	26
Camera View	26
Swipe Down - Control Center	27
Firmware Update	27
4 Using the Product	28
4.1 Setting the Shooting Mode	28
4.2 Selecting the Gimbal Mode	28
4.3 ActiveTrack	30
4.4 Smart Gimbal Mode	30
Multi-Person Tracking/Spotlight Follow	30


	Dynamic Framing	31
	SpinShot	31
4.5	Webcam Mode	32
4.6	Footage Storage and Transfer	32
	Storage Space	32
	Transferring Files	33
	Transferring Files to a Mobile Device	33
	Transferring Files to a Computer	34
4.7	Usage Notes	34
	Battery	35
5	Specifications	36

1 Product Profile

Different combos include different accessories. The accessories can be purchased separately. Visit the [official store](#) for a full list of compatible accessories.

Accessories	Standard Combo	Power Expansion Combo	Creator Combo	Vlog Combo
Osmo Pocket 4 Handle With 1/4" Thread (hereinafter referred to as "handle with 1/4" thread")	✓	✓	✓	✓
Osmo Pocket 4 Fill Light (hereinafter referred to as "fill light")	✓	✓	✓	✓
Osmo Mini Tripod	-	✓	✓	✓
Osmo Pocket 4 Battery Handle (hereinafter referred to as "battery handle")	-	✓	-	-
Osmo Pocket 4P Wide-Angle Lens	-	-	✓	-
DJI Mic 3 Transmitter	-	-	✓	-
DJI Mic Mini 2 Transmitter	-	-	-	✓
Osmo FrameTap	-	-	✓	✓

1.1 Overview



- 1. Camera
 - a. Mid-Tele Camera
 - b. Wide-Angle Camera
- 2. Rotatable Touchscreen
- 3. Zoom Button
- 4. Status LED

Blinking Pattern	Descriptions
Solid green	Ready to use
Temporarily off and stays green	Taking a photo
Blinks red slowly	Recording a video
Blinks red three times rapidly	Powering off, or about to power off because of low battery
Blinks red and green alternately	Updating firmware

- 5. 5D Joystick
- 6. microSD Card Slot (with Cover)

⚠ The microSD card slot cover is not waterproof. DO NOT forcefully pull the cover.

7. Quick-Release Slot
8. USB-C Port
9. Shutter/Record Button
10. Speaker
11. Custom Button
12. Tilt Motor
13. Microphones

 For better audio quality, DO NOT block the microphones when recording video.

14. Lanyard Hole
15. Pan Motor
16. Roll Motor
17. Contacts


 Ensure the contacts are clean and dry before attaching any accessories.

18. Osmo FrameTap (hereinafter referred to as "remote controller")
 - a. Function Button
 - b. Joystick
 - c. Shutter/Record Button

 The remote controller is only included in the Creator and Vlog Combos.


1.2 Handle With 1/4" Thread

Attach the handle with 1/4" thread to the camera for a more comfortable grip.




- ⚠ After shooting high-specification videos for an extended period, the upper part of the product may become hot. DO NOT hold too high to avoid high temperatures. The camera will stop shooting if any overheating is detected.
- The handle is not waterproof. DO NOT drop it in water. Avoid spilling any liquid on the handle.

When detaching, press and hold the release button on the handle and unplug the handle.




1.3 Battery Handle



- ⚠ • After shooting high-specification videos for an extended period, the upper part of the product may become hot. DO NOT hold too high to avoid high temperatures. The camera will stop shooting if any overheating is detected.
- When the battery handle is mounted to the camera, its firmware will be updated automatically during the camera firmware update. A prompt appears on the camera when the update is successful. DO NOT remove the battery handle before the update is complete.
- Make sure the battery handle has power when used with external audio devices.
- Make sure the battery handle is properly insulated to prevent fire hazards. DO NOT drop or strike the battery handle.
- If any foreign object is obstructing the USB-C port, use an air blower, soft brush, or other tools to clean the USB-C port and remove the foreign object. Note to sweep from the inside of the port to the outside.
- The handle is not waterproof. DO NOT drop it in water. Avoid spilling any liquid on the handle.
- Discharge the battery handle to 50% battery level if it is not used for 10 days or more in order to extend the battery life.

When detaching, press and hold the release button on the battery handle and unplug the handle. After the battery handle is detached, press the release button once to check the battery level.



⚠ Before charging, make sure the ports are clean and dry. Clean the ports with a dry cloth if there is any noticeable buildup.

Status LED

Battery Level Indicator

Solid red for 3s and turns off	1% - 19%
Solid yellow for 3s and turns off	20% - 49%
Solid green for 3s and turns off	50% - 100%

Blinks red three times 0%


Battery Level During Charging

Blinks green four times	> 75%
Blinks green three times	51% - 75%
Blinks green twice	26% - 50%
Blinks green slowly	0% - 25%
Off	Charging completed


System Status	
Blinks red and green alternately	Updating firmware
Blinks red twice	The ambient temperature is abnormal, and the battery handle cannot be used at this time. Wait until the temperature returns to normal.
Blinks yellow	Firmware update failed (connect to the camera and try update again)

1.4 Fill Light


Attach and adjust the angle:



Adjust color temperature:




Adjust brightness or turn off the fill light:




- After attaching the fill light, adjust the gimbal tilt angle to avoid lens flare.
- ⚠ • This product contains magnets. Keep the product away from magcards, implantable medical devices such as pacemakers, hard disks, RAM chips, and other devices to avoid interference.
- Before attaching the fill light, clean the contacts with a dry cloth if there is any noticeable buildup.
- When attaching the fill light, make sure it is correctly aligned with the gimbal to ensure a secure attachment.
- Avoid excessive shaking or sudden movements to prevent the fill light from falling.
- When installing or using the fill light, avoid collisions between the fill light and the gimbal camera.
- Before storing the camera, remove the fill light and then power off the camera.

1.5 Wide-Angle Lens

Remove the original protective lens before installation. Hold the camera with your thumb and index finger, and rotate the lens counterclockwise to unlock and remove it. DO NOT remove by force. Otherwise, the gimbal may be damaged.




When attaching, press the lens down firmly and rotate clockwise until it locks into place. Make sure the lens is securely attached to prevent it from falling off.




-
- ⚠
- After installation, the FOV of the wide-angle camera will be extended while the mid-tele camera remains unaffected.
 - The wide-angle lens is not suitable for shooting panoramic photos.
 - Keep the camera lens and both sides of the wide-angle lens clean. Dust or sand may scratch the lens and result in the wide-angle lens falling off.
 - Before storing the camera, remove the lens and then power off the camera.
-

1.6 Osmo Mini Tripod



2 Getting Started

2.1 Powering On



-
- When not recording, press and hold the Shutter/Record button or rotate the touchscreen counterclockwise to power off. To keep the camera on after rotation, swipe down in the camera view to open the Control Center, tap  > **Rotate screen to power off** to modify the settings.
-

2.2 Activation

Make sure to activate the camera using DJI Mimo App before first use.

1. Scan the QR code on the screen to download the DJI Mimo App.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Launch DJI Mimo App on the mobile device, tap the camera icon to connect to the camera, and then follow the instructions to activate the camera.

When the camera is used with the DJI Mimo App, you can monitor the current camera view, set the camera parameters, and control the camera with a mobile device.

-
-  • To check the Android and iOS operating system versions supported by the app, visit <https://www.dji.com/downloads/djiapp/dji-mimo>.
 - The interface and functions of the app may vary as the software version is updated. Actual user experience is based on the software version used.
-
- If Osmo FrameTap is included in your combo, make sure to power off the remote controller before connecting the camera to the DJI Mimo App for activation.
 - If there is a problem when connecting to DJI Mimo App, follow the steps below:
 1. Make sure both Wi-Fi and Bluetooth are enabled on the mobile device.

2. Make sure the DJI Mimo App is updated to the latest version.
3. In the liveview, swipe down from the top of the screen and tap **Wireless Connection > Reset Connection**. The camera will reset all connections and Wi-Fi passwords.

2.3 Firmware Update

A prompt will appear in DJI Mimo App when new firmware is available. Tap the prompt and follow the on-screen instructions to update the firmware.


💡 If the update fails, follow the steps for troubleshooting.

1. Restart the camera and DJI Mimo App.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo App and try the update again.

Contact DJI Support if the update fails again.

2.4 Charging

Use the provided cable to connect the USB-C port to a charger. It is recommended to use a USB-C PD charger.



💡 If the battery handle is mounted, the battery handle will not start charging until the battery of the handheld gimbal camera is fully charged.

⚠ Before charging, make sure the ports are clean and dry. Clean the ports with a dry cloth if there is any noticeable buildup.

3 Basic Operations

3.1 Button Features


5D Joystick

Controlling Gimbal Movement or Camera Zoom

Push left or right: Control the camera movement in the pan axis.

Push up or down: Control the camera tilt or zoom.

* The amount of joystick movement controls the gimbal rotation speed and camera zoom speed. The further the joystick is pushed, the faster the gimbal camera rotates or zooms. To disable this feature, swipe down from the top of the camera view, tap  and enable **Input Lock**. This setting allows for stable zoom control.



Other Operations

Press once: Go back to the previous menu, or exit ActiveTrack.

Press twice: Recenter the gimbal.

Press three times: Switch the camera between facing forward and backward.

Press and hold: Lock the gimbal or lock the camera direction.



Shutter/Record Button

Press once in the camera view: Take a photo or start/stop recording.

Press once when powered off: Power on.

Press and hold: Power off.



Zoom Button

Press once: Switch to 3x zoom.

Press twice: Switch to 6x zoom.

Press and hold: Continuously zoom in.

Press once at any zoom level to switch back to 1x zoom.



Custom Button

Swipe down from the top of the camera view to open the Control Center and tap  to customize the button functions.

By default:

Press once: Switch joystick control of gimbal tilt or camera zoom.

Press twice: Recenter the gimbal.


Press three times: Lock/unlock the camera direction.

Press and hold: Continuously zoom out.

3.2 Operating the Touchscreen

Camera View


After the camera powers on, the touchscreen shows the liveview.



- 1. Liveview**
Single tap the liveview to focus and meter. Double tap to select an [ActiveTrack](#) subject.
- 2. Storage Capacity/Remaining Recording Time**
- 3. Smart Gimbal Mode**
- 4. Shooting Mode**
Tap to select the shooting mode.
- 5. Shooting Specifications**
- 6. Zoom Levels**
Tap to quickly switch the zoom level.
- 7. Gimbal Rotate**
Tap to switch the camera between facing forward and backward.
- 8. Joystick Control**
Tap to switch joystick control between gimbal tilt and camera zoom.
- 9. Battery Level**
When the battery handle is mounted, tap the icon to view the battery levels of both the camera and the battery handle.

Swipe Up - Parameter Settings


Swipe up from the bottom of the screen to set the parameters for each shooting mode. Once you have set the parameters, swipe down from the top of the screen to return to the liveview.



- Various parameters can be set in different shooting modes. Refer to the actual interface.

Swipe Left - Image and Audio Settings

Swipe left in the camera view to adjust image and audio settings. Tap **PRO** to adjust pro parameters.




D-Log modes are designed for professional color grading when post-editing. In high-contrast or multi-color scenarios (e.g., garden, field, etc.), it can enlarge the dynamic range for more color-grading in post-production. When D-Log 10bit/D-Log 2 10bit color mode is selected, you can enable Color Recovery to preview the color rendering in the camera view.



Focus Mode, Beautify, App Glamour Effects, Film Tone and other settings are also supported. Click to watch the [tutorial video](#). Film Tone and Beautify are only available in Video mode and cannot be used simultaneously.

Swipe Right - Playback


Swipe right from the screen to view the last taken footage.



When playing back the video, long press any blank area on the screen to play at double speed. During playback, swipe left from the right edge of the screen to return to the liveview.

Swipe Down - Control Center

Swipe down from the top of the screen to enter the control center. Swipe up from the bottom of the screen to return to the liveview.



1. Custom Mode

Save the current shooting settings as a custom mode. Custom modes can then be used directly to shoot similar scenes.

2. Wireless Microphone

The camera can connect to two DJI wireless microphone transmitters simultaneously. Visit the official website to view the supported models.

Follow the on-screen instructions for linking. Once linked, you can use the transmitter to control the camera to start recording, with the audio being captured by the transmitter.

- Visit the DJI website and refer to the user manual of the mic product for more information.

- When the transmitter is linked to the camera, tap Wireless Microphone settings to adjust the audio parameters of the transmitter.
- Enter the control center, tap , and enable **Audio Backup**. When enabled, the camera's built-in microphone will also record audio simultaneously while recording video with a wireless microphone. This backup audio can be saved as a separate .aac file or embedded as an additional audio track in the video file. Audio Backup is not supported in Timelapse, Webcam, and DisplayPort transmission modes.

3. Fill Light

Tap to enter the fill light settings page, where you can turn on/off the fill light, or set auto fill light functions.

4. Gesture Control

When enabled, face the camera and perform the corresponding gesture to take photos, record videos, or control ActiveTrack:

- Palm  : Enable/disable ActiveTrack.
 - V Gesture  : Take a photo, or start/stop video recording.
-
-  The effective range for gesture control depends on the lens focal length. Refer to <https://www.dji.com/osmo-pocket-4p/faq> for details. Perform control gestures within the effective range, and avoid obscuring your face with your hand. There will be an on-screen prompt when the gesture takes effect.
 - When **Registered Subjects Only** is enabled, only registered subjects can control the camera with gestures.

5. Settings

Gimbal Calibration, Auto Power Off and other settings are also supported. Key features are as follows:

Gimbal Startup Direction	Set the direction the camera faces when powered on. Last Setting: if the gimbal mode is set to Follow or Tilt Locked, the camera will face forward or backward. If the gimbal mode is FPV, the camera will rotate to resume the same orientation when powered off last time.
Wearable Mode	After enabled, the camera will rotate and lock in the selfie mode and the gimbal mode will change to Tilt Locked. Tap twice on the screen to recenter the gimbal. Swipe up to exit Wearable mode. In wearable mode, it is recommended to use the camera with the Expansion Adapter (sold separately).

Press & Hold Joystick	Set the press-and-hold function of the joystick to lock the gimbal or camera direction.
Anti-Flicker	Tap to select the anti-flicker frequency to reduce flicker caused by fluorescent lights or TV screens when shooting indoors. Select the anti-flicker frequency according to the power grid frequency in the region. The default anti-flicker frequency is set as Auto.
Timecode	Either reset the timecode or sync with the system time. The camera timecode can be synchronized by a time code synchronizer using the USB-C port. Tap Timecode Display to display the time code in the liveview.

6. Custom Button

Customize the button functions.

7. Rotational Speed

Tap to adjust the gimbal following speed.

8. Selecting the Gimbal Mode

9. Register Subject

Register and manage the subject. Registered subjects can be prioritized for autofocus, gesture control, and Spotlight Follow.

10. Switching between Landscape and Portrait Mode

Tap and select the shooting orientations: Auto-Rotation, Landscape, and Portrait.

11. Screen Rotate & Capture

When this function is enabled, footage shooting will be started as soon as you rotate the touchscreen clockwise to power on the camera. Last Settings are used by default.

-  • After shooting, the camera will automatically power off if left idle for two seconds.
- When you rotate the screen again during recording:
 - If the shooting orientation is set to Auto-Rotation or Landscape, the recording stops and the camera will power off after two seconds.
 - If the shooting orientation is set to Portrait, shooting will continue.

12. Brightness

Tap and slide to adjust the brightness. You can also enable adaptive brightness for outdoor use.

13. FT (Selfie)

When the gimbal is in selfie orientation, the camera automatically tracks the subject occupying the largest area of the frame. Tracking stops when the gimbal orientation is reversed.

14. Selfie Flip

When enabled, footage captured in selfie mode is automatically mirrored to match the preview.

15. Sounds

Tap to set volume.

16. Reference Line


Display reference lines in the camera view to assist with composition.

3.3 Remote Controller Operations

Osmo FrameTap can be connected to Osmo Pocket 4P for remote control and previewing real-time camera feed.

- After powering on, the remote controller will automatically search for nearby devices. Follow the on-screen instructions to complete the connection.
- To ensure stable control, keep the remote controller within 10 m of the camera.

Button Features




Function Button

Press and hold: Power on/off.

Press once: Switch to 3x zoom.

Press twice: Switch to 6x zoom.

Press once at any zoom level to switch back to 1x zoom.




Joystick

Push left or right: Control the camera movement in the pan axis.

Push up or down: Control the camera tilt or zoom.

Press twice: Recenter the gimbal.


Press three times: Switch the camera between facing forward and backward.



Shutter/Record Button
Press once: Take a photo or start/stop recording.

Operating the Touchscreen

Camera View




- 1. Liveview**
Double-tap the liveview to select an ActiveTrack subject and start tracking. The camera will automatically center the subject while tracking.
- 2. Storage Capacity/Remaining Recording Time**
- 3. Playback**
Tap to view the last photo or video captured or played back.
- 4. Shooting Mode**
Tap to select the shooting mode.
- 5. Shooting Specifications**
Shooting specifications are only displayed in certain shooting modes.
- 6. Gimbal Rotate**
Tap to switch the camera between facing forward and backward.
- 7. Joystick Control**
Tap to switch joystick control between gimbal tilt and camera zoom.
- 8. Battery Level**

Tap to view the battery levels of the camera and the remote controller.

Swipe Down - Control Center

Swipe down from the top of the screen to enter the control center for more operations.



1. [Selecting the Gimbal Mode](#)
2. [Switching Connected Devices](#)
3. [Settings](#)
4. [Storage Space](#)

Check the storage information, or switch between internal storage and microSD card.

Firmware Update

The remote controller firmware can be updated via the DJI Mimo App.

1. Power off the camera and power on the remote controller. Ensure the remote controller battery level is sufficient.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Run the DJI Mimo App, tap the camera icon on the home screen, and connect the remote controller.
4. A prompt will appear in the app when new firmware is available. Tap the prompt and follow the on-screen instructions to update the firmware.



If the update fails, follow the steps for troubleshooting.


1. Restart the camera and DJI Mimo App.
2. Enable Wi-Fi and Bluetooth on the mobile device.
3. Connect the camera to DJI Mimo App and try the update again.

Contact DJI Support if the update fails again.

4 Using the Product

 The following operations use the camera touchscreen as an example. The interface and operations may vary when using the remote controller. Refer to the [Remote Controller Operations](#) section for more information.


4.1 Setting the Shooting Mode




1. Tap the icon to enter the mode switch page.
2. Swipe to select a shooting mode.
3. Tap the selected shooting mode or swipe up from the bottom of the screen to return to the liveview.

4.2 Selecting the Gimbal Mode


Swipe down from the top of the screen to enter the control center. Tap the icon to select the gimbal mode. Click to watch the [tutorial video](#).



Follow

The pan and tilt axis follow the handle while the roll axis remains level.



Follow mode is selected by default and is suitable for most scenarios, including vlogs and selfies.

Tilt Locked


Only the pan axis follows while the tilt axis is locked and the roll axis remains level.

This mode is suitable for push-in/pull-out and lateral movement shots.

The camera rotates freely and follows the handle movement. This mode is suitable for creative shots or immersive first-person view footage.

FPV / FPV⊥**FPV**


The camera keeps horizontally forward when powering on or re-centering.

FPV⊥

The camera keeps perpendicular to the handle when powering on or re-centering.

4.3 ActiveTrack

When in Photo or Video mode, ActiveTrack can be enabled in the camera view.




- **Frame Tracking:** The camera automatically matches and selects an ActiveTrack subject. Press the joystick once to start tracking the subject while maintaining the current composition.
- **Centered Tracking:** Double-tap a subject in the camera view to start tracking. The camera will automatically center the subject while tracking.

Press the 5D joystick or tap the touchscreen to exit ActiveTrack.

 ActiveTrack is unavailable in Panorama, Timelapse, Motionlapse, SpinShot, or when using FPV mode with the camera held horizontally.

4.4 Smart Gimbal Mode

In Video mode, tap  to select the smart gimbal mode. Tap  > **Exit** to exit the smart gimbal mode.



The following features are supported:

Multi-Person Tracking/Spotlight Follow

- **Multi-Person Tracking:** When enabled, the camera automatically tracks multiple subjects in the camera view and keeps them centered while tracking.


- **Spotlight Follow:** When enabled, the camera automatically follows the subject closest to the center of the frame. If there is a registered subject, the camera only follows that subject.

Dynamic Framing

Select the subject position in the live view based on the golden ratio or the rule of thirds via the 5D joystick. After the subject enters the frame, press the joystick to track the subject while keeping the subject at the selected position.

SpinShot

Press the joystick once or tap the icon on the screen to start SpinShot mode. The camera will rotate 90° or 180° to capture footage, creating a distinctive cinematic effect.



4.5 Webcam Mode

The product can work as a webcam on a computer. Power on the product and connect it to the computer using a USB cable. Tap **Webcam** on the camera to enter the Webcam mode, and the camera will function as a webcam input device. The bottom of the screen displays Webcam.

Press the Shutter/Record button to start recording. Disconnect the computer and the camera to exit Webcam mode.


 Ensure that the device is adequately cooled during use. Disconnect the device promptly after shooting is completed.

4.6 Footage Storage and Transfer


-
-  • To ensure a secure connection, it is recommended to use the provided data cable. If using third-party cables, select safe and reliable ones to ensure device performance and safety.
- Ensure that the microSD card slot and the microSD card are clean and free of foreign objects during use.
 - DO NOT remove the microSD card during recording. Otherwise, the microSD card may be damaged and cause data loss.
 - Before shooting important photos or videos, shoot a few images to test whether the camera is operating correctly.
 - Make sure to back up all important data stored in the internal storage or on the microSD card. Data cannot be restored if damaged or lost. Users are responsible for any loss caused by data loss in the internal storage.
-

Storage Space

Swipe down from the top of the screen, and then swipe left to check the storage information.



The camera has built-in storage and also supports expanding storage by installing a microSD card. Refer to [Specifications](#) for the recommended microSD cards.



Tap **Storage** to switch between internal storage and microSD card storage, and format the internal storage or microSD card.

 **Formatting will permanently delete all data. Make sure to back up all required data before formatting.**

Transferring Files

-
-  When transferring files by cables, if the camera cannot automatically recognize the connected device, enter the control center, tap  > **USB mode**, and reconnect the camera.
-


Transferring Files to a Mobile Device

- Connect the camera to DJI Mimo App, tap the album icon to preview photos and videos. Click  to download photos and videos.
- You can also transfer photos and videos by cables. Use the provided cable to connect the mobile device. When connected, view and transfer photos and videos via the device album or file management.

The photos and videos can be shared directly from DJI Mimo App to social media platforms.

Transferring Files to a Computer

Power on the camera and connect it to a computer using a USB-C cable. When connected to a computer, a pop-up appears. Tap **Transfer File: USB** to download the files from the camera to the computer. When transferring a file, the camera cannot take photos or record videos.



 Reconnect the device to the computer if a file transfer is interrupted.

 After file transfer is complete, DO NOT immediately disconnect the device to prevent data loss. Wait for the safe-to-remove prompt on your computer before disconnecting.

4.7 Usage Notes

1. Intricate components inside the device may be damaged upon impact and cause the gimbal to malfunction. Handle with care. Keep the product away from sand and dust to safeguard the device.
2. Make sure there is nothing obstructing the gimbal when the device is powered on.
3. DO NOT manually adjust the axis lock frequently to avoid causing the axis lock to malfunction.
4. The product is not water resistant. DO NOT spill any liquid on the product or use any liquid cleansers. Only use a soft dry cloth to clean the product.
5. DO NOT cover or touch the ventilation area of the product as it may become hot during use. When overheating, the camera will stop shooting.
6. DO NOT use the product in the environments with high-amplitude vibrations (such as installing on the handlebar of motorcycle or bike). Otherwise, the gimbal can be damaged.

7. Slight friction between the screen frame and the body is a normal phenomenon and does not affect use when rotating the screen.
8. DO NOT expose the camera lens in an environment with laser beams, such as a laser show, in order to avoid damaging the camera sensor.
9. Shaking the camera during power-on may cause startup failure. Hold the camera still while powering on.

Battery

1. DO NOT use non-official batteries. DJI takes no responsibility for any damage caused by non-official batteries.
2. Use the battery within the temperature range specified at <https://www.dji.com/osmo-pocket-4p/specs>. Use of the battery in a high-temperature environment can lead to a fire or explosion. Before using the battery in a low-temperature environment, it is recommended to charge the battery fully in a normal temperature environment. Charging the battery at the ideal temperature can prolong battery life.
3. Discharge and charge the battery completely once every three months to keep it in good condition.
4. The battery is designed to stop charging when it is fully charged. It is good practice to monitor the charging progress and disconnect the charger when battery is fully charged.
5. When the battery voltage is too low, the battery will enter low-power state. Charging the battery will exit low-power state.
6. DO NOT store the battery for an extended period of time after fully discharging. Otherwise, the battery may over-discharge and cause irreparable damage to the battery cell.
7. Discharge the battery to 40-65% if it will not be used for 10 days or more. This can greatly extend the battery life.

5 Specifications

Visit the following website for specifications.

<https://www.dji.com/osmo-pocket-4p/specs>



Contact

DJI SUPPORT

This content is subject to change without notice.

Download the latest version from



<https://www.dji.com/downloads/products/osmo-pocket-4p#doc>

If you have any questions about this document, please contact DJI by sending a message to DocSupport@dji.com.

DJI and OSMO are trademarks of DJI.

Copyright © 2026 DJI All Rights Reserved.